


Quick Installation Guide

AC600 Wireless Dual Band USB Adapter

System requirement:
Windows 8 Windows 7 Windows XP




For more information, please visit our website: <http://www.tp-link.com>

7106504670 REV1.0.0


1 Connect to a Computer

Insert the adapter into a USB port on your computer, either directly or via the USB cable provided.

Option 1




Option 2



Note: In Windows XP, a Found New Hardware Wizard window will pop up after the adapter has been inserted. Please click Cancel.


2 Install the Software

* You can also download the driver at www.tp-link.com/en/ if your computer can access the Internet via a wired connection.




Note:
If the Resource CD screen does not display, browse the files on the CD and double-click Autorun.exe.

Insert the TP-LINK resource CD into the CD-ROM drive. The Resource CD screen will pop up automatically.



Select the model Archer T2U and click **Install Driver and Utility**.



The **Install Shield Wizard** window will appear. Click **Next** and follow the instructions to finish the installation process.

3 Join a Wireless Network

Select your target wireless network from the list and click **Connect**. If the network is secure, enter its password. The symbol indicates a successful connection.

