# RK419WALVS

4U 19in Secure Horizontal Wall-Mountable Server Rack with Fans


## **Installation Guide**

## **Packaging Contents**

- 1 x RK419WALVS wall mount rack
- 16 x #10-32 Cage Nuts and Screws
- 1 x Set of keys
- 1 x Installation Guide

### **Installation**

1.To affix the wall-mountable rack to a wall, there are 4 anchor points on the rear. Open up the enclosed rack by unlocking the side lock with the provided key, then releasing the side latch.







**Specifications** 

Description	4U 19in Secure Horizontal Wall-Mountable Server Rack with Fans
Material	SPCC
Color	Black
Mounting Holes	Square
Cooling Fans	2
Fan Air Flow Rate	2.6 CFM
Fan Noise	42 dBa
Maximum Weight Capacity	68 kg
Available Internal Height	4U
External Dimensions (WxDxH)	643.0mm x 222.0mm x 726.0mm
Net Weight	20.12 kg
Standards	EIA RS-310D
Certifications	UL, CE, RoHS

The two halves of the rack should now swing apart horizontally via the side hinges. All four anchor points should now be easily accessible.





- 2.Use the appropriate screws or bolts for mounting heavy equipment to the specific type of wall/surface. Please observe proper safety procedures and use the appropriate tools.
- 3.Once securely fastened to a wall/surface, equipment can be mounted into the rack. Some cage nuts and screws are provided for mounting equipment into the rack. Cables, including the power cable for the cooling fans, can be routed through the bottom/rear of the rack.

Additional cage nuts and screws can be purchased from www.startech.com.



4. The top cover can be opened via key, as a quick way to check the status of equipment inside the rack or just extra ventilation.



#### Use of Trademarks, Registered Trademarks, and other Protected Names and Symbols

This manual may make reference to trademarks, registered trademarks, and other protected names and/or symbols of third-party companies not related in any way to StarTech.com. Where they occur these references are for illustrative purposes only and do not represent an endorsement of a product or service by StarTech.com, or an endorsement of the product(s) to which this manual applies by the third-party company in question. Regardless of any direct acknowledgement elsewhere in the body of this document, StarTech.com hereby acknowledges that all trademarks, registered trademarks, service marks, and other protected names and/or symbols contained in this manual and related documents are the property of their respective holders.

#### **Technical Support**

StarTech.com's lifetime technical support is an integral part of our commit-ment to provide industry-leading solutions. If you ever need help with your product, visit www.startech.com/support and access our comprehensive selection of online tools, documentation, and downloads.

#### **Warranty Information**

This product is backed by a lifetime warranty.

In addition, StarTech.com warrants its products against defects in materials and workmanship for the periods noted, following the initial date of purchase. During this period, the products may be returned for repair, or replacement with equivalent products at our discretion. The warranty covers parts and labor costs only. StarTech.com does not warrant its products from defects or damages arising from misuse, abuse, alteration, or normal wear and tear.

#### **Limitation of Liability**

In no event shall the liability of StarTech.com Ltd. and StarTech.com USA LLP (or their officers, directors, employees or agents) for any damages (whether direct or indirect, special, punitive, incidental, consequential, or otherwise), loss of profits, loss of business, or any pecuniary loss, arising out of or related to the use of the product exceed the actual price paid for the product. Some states do not allow the exclusion or limitation of incidental or consequential damages. If such laws apply, the limitations or exclusions contained in this statement may not apply to you.