


Mounting instructions for universal flat to wall TV bracket.
 VESA 200/300/400/600 x 400 - Universal up to 680mm X 475mm
 37" to 65" (94cm to 165cm) - Up to 75Kgs

Model No.
PMVMOUNT2036F

Factory No.
Z0840B


Read these instructions carefully before installing your equipment.
 Install the wall bracket in a suitable location using fixings which are appropriate for the wall material and structure. Consult a qualified builder if you're in any doubt as to the structural integrity of the wall.
 Do not attempt to alter or modify any part of the wall mount or its attachments.
 Do not use if any parts are broken or appear to be damaged.
 Tighten all bolts and fixings securely. Only use fixings provided with this bracket.
 Do not mount your TV close to sources or heat or moisture.
 Always have a minimum of two persons to install the wall bracket and TV.

TV Fixing Kit



A - M6 x 30mm
B - M8 x 30mm
C - M8 x 50mm

X4



D - M8 x 20mm

X4



E - M6
F - M8

X4



G - M8 x 6.5mm
H - M6 x 6.5mm

X4



I - M8 x 6mm
J - M8 x 12.5mm


X4




K - M6 x 20mm

X2

Also required




1 Mount Bracket To Wall




NOTE:

For ease of installation mount bracket on wall using position 1 and mark other positions using a spirit level. Then remove fixing from position 1, remove bracket and drill other positions.
 Use Fixings suitable for your type of wall construction. (Not included).
 Use All available fixing points.
 If in any doubt of the suitability of the wall, its construction or what type of fixings to use, consult a qualified builder or installer.

2 Attach Screen Fixing Plate To Screen



3 Hang And Secure Screen On TV Mounting Plate



b

